

Service Bulletin SB-273 Parts List

Part	Description	Quantity	Image
P16169	LABEL, HATCH / ÉTIQUETTE, TRAPPE	1	ALL BIDGES MOST FIELD AND UNDERSTAND OFFICE AND OFFICE
			CONCENSION OF A CONTINUE AND A CONTI
P11531	LABEL, ROTOR GUARD / ÉTIQUETTE, ROTOR GUARD	1	ROTATING PARTS CAN SEVERELY INJURE. THIS ROTOR GUARD MUST ALWAYS BE IN PLACE WHEN THE TRACTIVE UNIT (MOTOR-INVERTER) IS ACTIVE. PIEST
P11526	LABEL, PULLEY GUARD / ÉTIQUETTE, PULLEY GUARD	1	ROTATING PARTS CAN CRUSH AND CUT. THEY COULD CAUSE SEVERE INJURY OR CATCH CLOTHING. THIS GUARD MUST ALWAYS BE IN PLACE WHEN TRACTIVE UNIT (MOTOR-INVERTER) IS ACTIVE. P11526
P16170	LABEL, HATCH FR / ÉTIQUETTE, TRAPPE	1	TOTAL SEA GRANDERS OF THE SEA OF
P13198	LABEL, ROTOR GUARD FR / ÉTIQUETTE, ROTOR GUARD	1	LES PIÈCES EN ROTATION PEUVENT VOUS BLESSER GRAVEMENT. LE PROTÈGE- DISQUE DOIT TOUJOURS ÊTRE EN PLACE LORSQUE L'UNITÉ MOTRICE (MOTEUR- ONDULEUR) EST ACTIVE.
P13195	LABEL, PULLEY GUARD FR/ ÉTIQUETTE, PULLEY GUARD e: 15 Minutes	1	LES PIÈCES EN ROTATION PEUVENT ÉCRASER ET COUPER ELLES PEUVENT CAUSER DES BLESSURES GRAYES OU ENTRAINER LES VETEMENTS. LE PROTEGE-COURROIE DOIT TOUJOURS ÉTRE EN PLACE LORSQUE L'UNITÉ MOTRICE (MOTEUR- ONDULEUR) EST ACTIVÉE.

Service Time: 15 Minutes



Service Bulletin SB-273 Repair Procedure

Condition for Repair

Determine if the vehicle currently has the English labels or the French labels already applied.

Procedure

Clean the indicated areas from dirt and debris (Orange areas seen in the images below).

Wipe the area with IPA alcohol. *NOTE:* It is not necessary to remove the existing Hatch labels prior to cleaning. The newly applied Hatch labels will adhere on top of the old labels.




If English labels are already applied

Apply the provided label P16169
 "LABEL, HATCH" to the designated area:




2. Apply the provided label P13195 "LABEL, PULLEY GUARD FR" to the

designated area (ORANGE). (Blue indicates the existing label location).



3. Apply the provided label P13198 "LABEL, ROTOR GUARD FR" to the designated area (ORANGE). (Blue indicates the existing label location).






If French labels are already applied

1. Apply the provided label P16170 "LABEL, HATCH FR" to the designated area:



2. Apply the provided label P11526 "LABEL, PULLEY GUARD" to the designated area (ORANGE). (Blue indicates the existing label location).



3. Apply the provided label P11531 "LABEL, ROTOR GUARD " to the designated area (ORANGE). (Blue indicates the existing label location).

